


## 5-Pin MIDI Right Angle Plug Cable Exit Diagram



Please select from positions A thru H. Position can be changed by user at any time.